

Parking Lots

Last Modified on 12/31/2020 2:19 pm EST

Overview

There are two types of parking lots used to manage calls routed to destinations including specific users or a Call Ring Group Ring or to page all users:

- General Parking
- Valet Parking

General Parking works on a first in/first out basis and assigns calls to the first available extension in the lot. When a call is moved to the General Parking Lot, the user moving the call enters the main Parking Lot extension and waits for an audio response indicating which extension has received the parked call. General Parking Lots are used for physical phones and through Presence.

Valet Parking is ideal for specifying a specific Parking Lot extension when transferring a call. The advantage here is knowing the exact extension holding the parked call. However, if the selected extension is busy, the call will route back to the original destination for rerouting. Valet Parking can be useful from Bolt or a physical phone when utilizing Busy Lamp Field (BLF) keys.

A Synkato Admin uses the **Interaction Routing > Call Parking Lots** menu to create and manage Call Parking Lots.

Parking Lots appear on the main screen and can be sorted by Parking Ext name, Name, and Parking Slots column headers. Click the respective Parking Lot Ext or Name hyperlink to view more details. An unlimited amount of Parking Lots can be created to fit the needs of an organization, but each Parking Lot is limited to 10 slots.

The **ACTIONS** section on the right side of the screen contains an **Add Parking Lot** link.

The **SEARCH RESULTS** section on the right side of the screen contains frequent Parking Lot search results.

The screenshot displays the 'PARKING LOT MANAGEMENT > ALL PARKING LOTS' interface. The main content area shows 'Parking Lots (5/Unlimited)' with a search bar and a table of results. The table has columns for 'Parking Ext', 'Name', and 'Parking Slots'. The search results on the right side of the screen include an 'Add Parking Lot' button and a list of search results for various parking lots.

Parking Ext	Name	Parking Slots
1030	Valet #1	1030 - 1039
1040	Switchboard	1040 - 1049
3335	Sales	3336 - 3341
4575	Main Parking Lot	4576 - 4581
8450	Valet Parking Lot	8450 - 8459

(Showing 5 of 5 results)

Navigation: First Previous **1** Next Last

ACTIONS

+ Add Parking Lot

SEARCH RESULTS

- 1030: Valet #1
- 1040: Switchboard
- 3335: Sales
- 4575: Main Parking Lot
- 8450: Valet Parking Lot

Add a Parking Lot

Click + Add Parking Lot under ACTIONS to create a new Parking Lot.

The screenshot displays the 'PARKING LOT MANAGEMENT' interface. The main content area is titled 'Parking Lots (3/Unlimited)' and contains a search bar with the text 'Search Parking Lots' and a dropdown showing 'Showing 37 Results'. Below the search bar is a table with three columns: 'Parking Ext', 'Name', and 'Parking Slots'. The table lists three parking lots: 3335 (Sales), 4575 (Main Parking Lot), and 8450 (Valet Parking Lot). At the bottom of the table, it says '(Showing 3 of 3 results)' and has navigation buttons for 'First', 'Previous', '1', 'Next', and 'Last'. On the right side, there is an 'ACTIONS' panel with a green button labeled '+ Add Parking Lot'. Below the actions panel is a 'SEARCH RESULTS' section with three blue buttons: '3335: Sales', '4575: Main Parking Lot', and '8450: Valet Parking Lot'.

Parking Ext	Name	Parking Slots
3335	Sales	3336 - 3341
4575	Main Parking Lot	4576 - 4581
8450	Valet Parking Lot	8450 - 8459

Parking Lot Information

Populate the following fields to establish Parking Lot details on the Parking Lot Information tab:

Parking Lot Name

Assign a name to the Ring Group that signifies the purpose of the group (e.g., Sales, Call Center or Management Team). This field is required.

Parking Lot Extension

Enter a destination number ending in 0 to assign to the Ring Group for direct dial or to page all users. This field is required (e.g., 1600, 5000 and 8800).

Valet Parking

Enable to save the Parking Lot as a Valet lot, meaning that the user specifies the exact Parking Space to park the call.

Valet Parking Lot extension format: Select a starting Parking Lot extension ending in 0.

NOTE: When Valet Parking is selected, the number of Parking Slots is 10 and cannot be changed.

Parking Lots

Enter the number of assigned parking slots for this Parking Lot. The maximum number for this field is 10.

PARKING LOT MANAGEMENT » ALL PARKING LOTS

Parking Lot Information **Timeout**

Parking Lot Details:

Parking Lot Name:

Parking Lot Extension: **Valet Parking:** Valet parking allows for one-touch parking/pick-up.

Parking Slots:

Parking Lot Slots: 6

+ Create Parkinglot

Timeout Settings

From this tab, establish timeout conditions on the Timeout tab:

Parking Timeout

Enter the amount of time in seconds that a call waits in the Parking Lot before routing back to the Time outflow destination.

Return to Origin


Check this box to route a caller back to the originating device that sent the call once the Parking Timeout has expired. When checked and the originating device sending the call is busy, the call is routed to the destination identified in the Timeout/Failover Overflow below.

When left unchecked, the call routes to the Timeout overflow destination. When a Timeout Overflow is not set, the call terminates.


Timeout/Failover Overflow

When **Return to Origin** is marked, this section displays the overflow destination as determined in the Call Flow. When an overflow has not been established, the following message appears:

Call Flow Overflow piece needs to be set in the Call Routing > Call Flow Tool.



A Synkato Admin sets the Timeout/Failover Overflow from **Interaction Routing > Flows**.



Programming Parking Lots

Physical phones and Synkato's Bolt Softphone allow a user to program buttons for Parking Lots.

Create a Parking Lot record in Bolt

Store the primary Valet Parking Lot extension and the system selects the first available slot and announces audibly where the call is being parked.

Valet Parking Lot example in Bolt:

